



# Standard Bladder Accumulator Spare Parts



## Recommended Spare Parts

### Bladder Kit

Bladder assembly  
Anti-extrusion ring assembly

### Anti-Extrusion Ring Assembly

Anti-extrusion ring, 'O' ring fluid port, back-up ring, sealed bleed valve ( 03 to 54L )

### Fluid Port Assembly

Body Fluid port, poppet valve assembly, flanged washer, locking ring, bleed valve assembly ( 03 to 54L )

Accumulator Reference	Oil Service Bladder Kit	Corrosion Service Bladder Kit	Oil Service Anti Ex-ring Assembly	Corrosion Service Anti Ex-ring Assembly	Oil Service Fluid Port Assembly	Corrosion Service Fluid Port Assembly
0B	0B00A-00	0B0SA-02	0B0**-00	0B0**-02	0B***-00	0B***-02
0F	0F00A-00	0F0SA-02	0F0**-00	0F0**-02	0F***-00	0F***-02
01C	01C00A-00	01C0SA-02	0F0**-00	0F0**-02	0F***-00	0F***-02
03C	03C00A-00	03C0SA-02	030**R7	03C0**-02	03C***-00	03C***-02
04	0400A-00	0400SA-00	040**-00	040**-02	04***-00	04***-02
10	1000A-00	100SA-02	100**-00	100**-02	10***-00	10***-02
20	2000A-00	200SA-02	100**-00	100**-02	10***-00	10***-02
28	2800A-00	280SA-02	100**-00	100**-02	10***-00	10***-02
37	3700A-00	370SA-02	100**-00	100**-02	10***-00	10***-02
54	5400A-00	540SA-02	100**-00	100**-02	10***-00	10***-02

Other rubber material information available upon request.

Accumulator Reference	Gas Valve Core	Gas Valve Assembly	'O' Ring Fluid Part	Back-up Ring	Oil Service Locking Ring	Corrosion Service Locking Ring
0B	43001-099	N/A	40127-A00	40366-P00	24950-V29	24950-006
0F	43001-099	N/A	40294-A00	40367-P00	25010-V29	25010-006
01C	N/A	10053-S03	40294-A00	40367-P00	25010-V29	25010-006
03C	N/A	10053-S03	40306-A00	40875-P00	25060-V29	25060-006
04	N/A	10053-S03	40002-A00	40369-P00	25100-V29	25100-006
10-54	N/A	10053-S03	40003-A00	40370-P00	25150-V29	25150-006

Note: Gas valve assembly integral with bladder on 0B to 0F accumulators. Protective cap fitted on 01-54L accumulators only. NA = Not applicable. Bleed assembly fitted on 03-54L accumulators only.